

修改标记	区域	修改内容	修改人	日期

高速手持风扇

H16使用说明书

安全指引

1.本产品不得由存在肢体、感官或精神能力缺陷或缺少使用经验和知识的人(包括儿童)使用,除非有负责他们安全的人对他们进行与本产品使用有关的监督或指导;

2.在使用本产品时应照看好儿童,确保他们不玩耍本产品。

3.本产品应仅使用标记在机身上的安全特低电压供电。

4.本产品包含只能由技术人员更换的电池。


5.本产品说明书电子档, 官方下载网站: <https://www.greatarmo.com>

产品参数

产品名称	高速手持风扇
产品型号	H16
充电输入	5V—1.6A
电池电压	3.7V
产品尺寸	180.5*62*58mm
执行标准	GB/T 4706.1-2024 ,GB/T 4706.27-2024

使用前请仔细阅读说明书，并保管好说明书

产品结构



使用说明

本产品共有二个版本：A标准版，B制冷版

% 电量百分比

❄ 冰敷模式指示灯

□ 标准版：

1：单击+键开启风扇，启动后显示风扇档位，风速默认为1档，继续单击+键增加风速，默认档位为：1-50-100-150-199-关机，启动风扇后长按+键可以逐档增加，长按-键可以逐档降低。单击-键档位风速逐档降低，默认档位为：199-150-100-50-1-关机，依次循环。

2：电量低于10%时，显示屏闪烁提醒，请及时进行充电。

3：充电：插入充电线后，电量百分比个位数闪烁，显示实时电量，电池充满后显示屏显示100%。

□ 制冷版：

1：单击⏻键开启风扇，启动后风速默认为1档，共199档风力，单击⏻键增加风速，默认档位为：1-50-100-150-199-关机，循环，长按逐档增加风速。


2：风扇开启后，按❄键开关启动冰敷模式，冰敷指示灯亮起进行工作，再按调档冰敷，C1-C2-C3-关闭，模式循环，冰敷模式不能单独使用。

3：电量低于10%时，显示屏闪烁提醒，请及时进行充电。

4：充电：插入充电线后，电量百分比个位数闪烁，显示实时电量，电池充满后显示屏显示100%。

5：充电过程中不能开启冰敷模式。

配件加挂绳



彩盒一套 说明书一张 数据线一条 挂绳一条 产品一台

警告

◆ 本产品内置密封电池，无法自行拆卸。

◆ 请勿在潮湿环境中（如浴室）使用本产品，接触水可能会导致产品故障或损坏。

◆ 请勿敲击或摔打本产品，反复敲击可能会导致内部损坏

◆ 请勿自行拆卸、更改或者修理本产品。

◆ 请勿将产品投入火中，以免发生爆炸危险。

◆ 若产品在充电过程中出现异常高温或变形，请立即停止充电并联系售后服务中心处理。

◆ 请勿让7岁以下儿童单独使用本产品。

产品合格证

产品名称：	高速手持风扇
产品编号：	
产品型号：	H16
生产日期：	
检验员：	01

High Speed Handheld Fan

H16 User manual

Safety Instructions

1.This product must not be used by persons with physical, sensory or mental impairments, or by those lacking experience and knowledge (including children), unless they are supervised or instructed by a person responsible for their safety in relation to the use of this product.

2.Children shall be supervised when this product is in use to ensure they do not play with it.

3.This product shall be powered only by the safety extra-low voltage (SELV) marked on the unit.

4.This product contains batteries that can only be replaced by a qualified technician.


5.Electronic version of this product manual is available for official download at: <https://www.greatarmo.com>

Product Specifications

Product Name	High Speed Handheld Fan
Model	H16
Charging Input	5V—1.6A
Battery Voltage	3.7V
Product Size	180.5*62*58mm
Compliance Standard	GB/T 4706.1-2024 ,GB/T 4706.27-2024

Read this manual carefully before use and keep it for future reference.

Product Structure



Instructions for Use

This product has two versions in total: A Standard Edition , B Refrigerated version

% Battery Percentage

❄ Ice Pack Mode Indicator

□ Standard Edition

1:Press the + button to turn on the fan. After starting, the fan speed level will be displayed, with the default speed set to level 1. Continue pressing the + button to increase the fan speed. The default levels are: 1-50-100-150-199-OFF. After the fan is started, holding down the button can increase the speed step by step, and holding down the - button can decrease the speed step by step. Pressing the -button will decrease the speed level step by step, with the default sequence: 199-150-100-50-1-OFF, cycling in order.

2: When the battery level is below 10%, the display will flash to alert you. Please charge promptly.

3: Charging: After plugging in the charging cable, the unit digit of the battery percentage will flash, showing the real-time battery level. Once fully charged, the display will show 100%.

□ Refrigerated version

1: Press the ⏻ button to turn on the fan. After starting, the fan speed is set to level1 by default, with a total of 199 speed levels. Press the ⏻ button to increase the fan speed. The default speed sequence is: 1-50-100-150-199-OFF, cycling through. Long press to increase the speed level by level.

2: After the fan is on, press the ❄ button to toggle the ice compress mode. The ice mode indicator light will turn on during operation. Press again to adjust the ice mode levels: C1-C2-C3-OFF, cycling through. The ice mode can not be used independently.

3: When the battery level is below 10%, the display will flash to remind you to recharge in time.

4: Charging: After connecting the charging cable, the single-digit battery percentage on the display will flash, showing the real-time battery level. When fully charged, the display shows 100%.

5: The ice compress mode cannot be activated while charging.

Product Accessories



Gift Box x1 User Manual x1 USB Cable x1 Lanyard x1 Product x1

Warnings

◆This product has a built-in sealed battery. Do not disassemble it by yourself.

◆Do not use in humid environments (e.g., bathrooms). Exposure to water may cause malfunction or damage.

◆Avoid impacts or dropping the product. Repeated shocks may damage internal components.

◆Do not disassemble, modify, or repair the product yourself.

◆Do not expose to fire or high heat to prevent explosion risks.

◆If abnormal overheating or deformation occurs during charging, stop use immediately and contact customer service.

◆Do not allow children under 7 years old to use this product unsupervised.

Product Certification

Product Name:	High Speed Handheld Fan
Product ID:	
Model:	H16
Production Date:	
Quality Inspector:	01

技术要求

1.印刷必须清晰不得有断线、模糊不清等不良现象；

2.背胶必须耐温80摄氏度且不会翘起；

3.标签必须符合“SPI环境管制物质技术标准（SGP-0401）”最新版。

4.公差为±0.1mm。



温馨提示：请印刷供应商严格按照我司设计图纸印刷生产。如贵司有生产上的原因需要调整图纸的字体、图形、颜色、刀模尺寸、材质工艺等，请必须通知我司相关负责的包装设计师，并在征得包装设计师同意的情况下修改文档并发回存档。

 大花猫科技 Greatarmo Technology Co.,Ltd	型号	H16	物料	说明书			颜色	黑白	
	材质	80g书纸			工艺	单色			
	设计		日期	2026年03月05日		尺寸	70×105mm		公差±0.1
	审核		日期			单位	mm	页码	1
	批准		日期			比例	1:1	版本	V1.0