

修改标记	区域	修改内容	修改人	日期

便携式挂腰风扇

W2使用说明书

安全指引

1.本产品不得由存在肢体、感官或精神能力缺陷或缺少使用经验和知识的人(包括儿童)使用,除非有负责他们安全的人对他们进行与本产品使用有关的监督或指导。

2.在使用本产品时应照看好儿童,确保他们不玩耍本产品。

3.本产品应仅使用标记在机身上的安全特低电压供电。

4.本产品包含只能由技术人员更换的电池。

5.本产品说明书电子档，官方下载网站：<https://www.greatarmo.com>

产品参数

产品名称	便携式挂腰风扇
产品型号	W2
充电输入	5V—2A
电池电压	3.7V
产品尺寸	94.5*72.3*97.3mm
执行标准	GB/T 4706.1-2024 ,GB/T 4706.27-2024

使用前请仔细阅读说明书，并保管好说明书

产品结构

风速显示屏

冰敷片

出风口

电源/冰敷/风速开关旋钮

短夹子

Type-c接口

使用说明

本产品共有二个版本：A标准版，B制冷版

% 电量百分比

※ 冰敷模式指示灯

☐ 标准版

1：长按旋钮1.5秒开关开启风扇，启动后显示风扇档位，风速默认为1档，继续单击增加风速，默认档位为：1-25-50-75-100-1档位循环，再任何档位情况下长按1.5秒开关机。

2：顺时针旋转旋钮，调整风速1到100档，逆时针旋转降低风速，风速100到1档。

3：电量低于10％时，显示屏闪烁提醒，请及时进行充电。

4：充电：插入充电线后，电量百分比个位数闪烁，显示实时电量，电池充满后显示屏显示100％。

☐ 制冷版

1：长按旋钮1.5秒开关开启风扇，启动后显示风扇档位，风速默认为1档，顺时针旋转旋钮，调整风速1到100档，逆时针旋转降低风速，风速100到1档。再任何档位情况下长按1.5秒开关机。

2：风扇开启后，单击旋钮开关启动冰敷模式，冰敷指示灯亮起进行工作，再按调档冰敷，C1-C2-C3-关闭，模式循环，冰敷模式不能单独使用。

3：电量低于10％时，显示屏闪烁提醒，请及时进行充电。

4：充电：插入充电线后，电量百分比个位数闪烁，显示实时电量，电池充 满后显示屏显示100％。

5：充电过程中不能开启冰敷模式。

产品配件

彩盒一套

说明书一张

数据线一条

挂绳一条

产品一台

警告

◆ 本产品内置密封电池,无法自行拆卸。

◆ 请勿在潮湿环境中（如浴室）使用本产品，接触水可能会导致产品故障或损坏。

◆ 请勿敲击或摔打本产品，反复敲击可能会导致内部损坏

◆ 请勿自行拆卸、更改或者修理本产品。

◆ 请勿将产品投入火中，以免发生爆炸危险。

◆ 若产品在充电过程中出现异常高温或变形，请立即停止充电并联系售后服务中心处理。

◆ 请勿让7岁以下儿童单独使用本产品。

产品合格证

产品名称：	便携式挂腰风扇
产品编号：	
产品型号：	W2
生产日期：	
检验员：	01

PORTABLE WAIST FAN

W2 User manual

Safety Instructions

1.This product must not be used by persons with physical, sensory or mental impairments, or by those lacking experience and knowledge (including children), unless they are supervised or instructed by a person responsible for their safety in relation to the use of this product.

2.Children shall be supervised when this product is in use to ensure they do not play with it.

3.This product shall be powered only by the safety extra-low voltage (SELV) marked on the unit.

4.This product contains batteries that can only be replaced by a qualified technician.

5.Electronic version of this product manual is available for official download at: <https://www.greatarmo.com>

Product Specifications

Product Name	PORTABLE WAIST FAN
Model	W2
Charging Input	5V~2A
Battery Voltage	3.7V
Product Size	94.5*72.3*97.3mm
Compliance Standard	GB/T 4706.1-2024 ,GB/T 4706.27-2024

Please read the manual carefully and keep it well before use

Product Structure

Display screen

Ice pack

Air vent

Power/ice/ wind speed switch knob

Short clip

Type-c

Instructions for Use

This product has two versions in total: A Standard Edition,B Refrigerated version

% Battery Percentage

※ Ice Pack Mode Indicator

☐ Standard Edition

1: Press and hold the knob for 1.5 seconds to turn on the fan.Once activated, the fan gear will be displayed, with the default wind speed set to Gear 1. Press the knob briefly again to increase the wind speed. The gears cycle by default in the following sequence: 1 - 25 - 50 - 75- 100 - 1. The fan can be turned ON or OFF by pressing and holding the knob for 1.5 seconds at any gear.

2: Rotate the knob clockwise to adjust the wind speed from 1 to 100, and counterclockwise to decrease the wind speed from 100 to 1

3: When the battery level is below 10%, the display screen flashes to remind you to charge it in a timely manner.,

4: Charging: After inserting the charging cable, the percentage of battery level flashes in single digits, displaying real-time battery level, and the battery is charged. The display screen shows 100% when full.

☐ Refrigerated version

1: Press and hold the knob for 1.5 seconds to turn the fan ON or OFF. Once activated, the fan speed level will be displayed, with the default speed set to Level 1. Rotate the knob clockwise to adjust the speed from Level 1 to Level 100, and rotate it counterclockwise to decrease the speed from Level 100 to Level 1. Press and hold the knob for 1.5 seconds to power the fan ON or OFF at any speed level.

2: After the fan is turned on, press the knob briefly to activate the ice compress mode. The ice compress indicator light will illuminate to indicate that the function is in operation. Press the knob again to switch between ice compress levels, which cycle in the sequence: C1 - C2 - C3 - OFF. The ice compress mode cannot be activated independently.

3: When the battery level drops below 10%, the display screen will flash as a reminder. Please recharge the device in a timely manner.

4: Charging: Once the charging cable is connected, the single-digit of the battery percentage will flash to display the real-time battery level. When the battery is fully charged, the display will show 100%.

5:The ice compress mode cannot be activated during charging.

Product accessories

Gift Box x1

User Manual x1

USB Cable x1

Lanyard x1

Product x1

Warnings

◆ This product has a built-in sealed battery. Do not disassemble it by yourself.

◆ Do not use in humid environments (e.g., bathrooms). Exposure to water may cause malfunction or damage.

◆ Avoid impacts or dropping the product. Repeated shocks may damage internal components.

◆ Do not disassemble, modify, or repair the product yourself.

◆ Do not expose to fire or high heat to prevent explosion risks.

◆ If abnormal overheating or deformation occurs during charging, stop use immediately and contact customer service.

◆ Do not allow children under 7 years old to use this product unsupervised.


Product Certification

Product Name:	Portable Waist Fan
Product ID:	
Model:	W2
Production Date:	
Quality Inspector:	01

技术要求

- 1.印刷必须清晰不得有断线、模糊不清等不良现象；
- 2.背胶必须耐温80摄氏度且不会翘起；
- 3.标签必须符合“SPI环境管制物质技术标准（SGP-0401）”最新版。
- 4.公差为±0.1mm。

温馨提示：请印刷供应商严格按照我司设计图纸印刷生产。如贵司有生产上的原因需要调整图纸的字体、图形、颜色、刀模尺寸、材质工艺等，请必须通知我司相关负责的包装设计师，并在征得包装设计师同意的情况下修改文档并发回存档。

	型号	W2	物料	说明书			颜色	黑白		
	材质	80g书纸			工艺	单色				
	设计		日期	2026年03月05日		尺寸	85×75mm		公差±0.1	
大花猫科技 Greatarmo Technology Co.,Ltd	审核		日期			单位	mm	页码	1	
	批准		日期			比例	1:1	版本	V1.0	

