

| 修改标记 | 区域 | 修改内容 | 修改人 | 日期 |
|------|----|------|-----|----|
|      |    |      |     |    |

## 高速手持风扇

### HL005使用说明书

安全指引


1.本产品不得由存在肢体、感官或精神能力缺陷或缺少使用经验和知识的人(包括儿童)使用,除非有负责他们安全的人对他们进行与本产品使用有关的监督或指导;  
2.在使用本产品时应照看好儿童,确保他们不玩耍本产品。  
3.本产品应仅使用标记在身上的安全特低电压供电。  
4.本产品包含只能由技术人员更换的电池。  
5.本产品说明书电子档，官方下载网站：https://www.greatarmo.com

产品参数

|      |                                     |
|------|-------------------------------------|
| 产品名称 | 高速手持风扇                              |
| 产品型号 | HI005                               |
| 充电输入 | 5V—2A                               |
| 电池电压 | 3.7V                                |
| 产品尺寸 | 172*60*51.5mm                       |
| 执行标准 | GB/T 4706.1-2024 ,GB/T 4706.27-2024 |

使用前请仔细阅读说明书，并保管好说明书

产品结构



登山扣说明



使用说明：用手指捏住弹簧扣锁扣，将绳带穿入登山扣内环，松开卡扣，弹簧自动回弹闭合，确认扣口完全密封、无缝隙即可正常使用。

注意事项：

- 禁止用于高空攀岩、绳索承重、人身防护等专业极限承重用途，仅作日常挂本产品使用；
- 避免超负荷承重，请勿悬挂超出产品额定承重的重物；
- 切勿强行暴力拉扯、摔砸、弯折登山扣，防止变形、断裂；
- 使用前检查扣口弹簧是否回弹顺畅、有无裂纹变形，异常请勿使用；

使用说明

1.长按电源键开启风扇，启动后显示电池电量百分比，风速默认为1档，共100档风力，向上滑动滚轮加速，向下滑动减速。

2.风扇开启后，长按冰敷开关启动冰敷模式，冰敷指示灯亮起进行工作，再次长按关闭冰敷，冰敷模式不能单独使用。

3.电量低于10%时，电也图标闪烁，请及时进行充电。

4.充电：插入充电线后，电池图标长亮，电量百分比会闪烁显示实时电量，电池充满后显示并显示100%。

5.充电过程中不能开启冰敷模式。

配件加挂绳



警告

◆本产品内置密封电池，无法自行拆卸。

◆请勿在潮湿环境中（如浴室）使用本产品，接触水可能会导致产品故障或损坏。

◆请勿敲击或摔打本产品，反复敲击可能会导致内部损坏

◆请勿自行拆卸、更改或者修理本产品。

◆请勿将产品投入火中，以免发生爆炸危险。

◆若产品在充电过程中出现异常高温或变形，请立即停止充电并联系客服后服务中心处理。

◆请勿让7岁以下儿童单独使用本产品。

产品合格证

|       |        |
|-------|--------|
| 产品名称： | 高速手持风扇 |
| 产品编号： |        |
| 产品型号： | HL005  |
| 生产日期： |        |
| 检验员：  | 01     |

## High Speed Handheld Fan

### HL005 User manual

Safety Instructions


1.This product must not be used by persons with physical, sensory or mental impairments, or by those lacking experience and knowledge (including children), unless they are supervised or instructed by a person responsible for their safety in relation to the use of this product.  
2.Children shall be supervised when this product is in use to ensure they do not play with it.  
3.This product shall be powered only by the safety extra-low voltage (SELV) marked on the unit.  
4.This product contains batteries that can only be replaced by a qualified technician.  
5.Electronic version of this product manual is available for official download at: https://www.greatarmo.com

Product Specifications

|                     |                                     |
|---------------------|-------------------------------------|
| Product Name        | High Speed Handheld Fan             |
| Model               | HL005                               |
| Charging Input      | 5V—2A                               |
| Battery Voltage     | 3.7V                                |
| Product Size        | 172*60*51.5mm                       |
| Compliance Standard | GB/T 4706.1-2024 ,GB/T 4706.27-2024 |

Read this manual carefully before use and keep it for future reference.

Product Structure



Product Specifications



Instructions: Pinch the spring latch with your fingers, pass the strap through the inner ring of the carabiner, then release the latch. The spring will automatically rebound and close. Ensure the opening is fully closed with no gaps before normal use.

Precautions:

- Do not use this product for high-altitude rock climbing, rope load-bearing, personal protection or other professional extreme load-bearing scenarios. It is only for daily hanging use.
- Avoid overloading. Do not hang heavy objects exceeding the rated load of the product.
- Do not forcibly pull, drop, strike or bend the carabiner to prevent deformation and fracture.
- Before use, check whether the spring latch rebounds smoothly and whether there is any crack or deformation. Do not use it if any abnormality is found.

Instructions for Use

1.Power On/Off:Long press the power button to turn on the fan. The battery percentage will display automatically. Default speed is Level 1 (adjustable from 1 to 100 levels).Swipe the wheel upward to increase speed or downward to decrease.


2.Ice Pack Mode: After turning on the fan, long press the ice pack switch to activate cooling mode(indicator lights up).Long press again to deactivate. Note: Ice pack mode cannot be used alone.

3.Low Battery Alert: When battery drops below 10%,the battery icon will flash. Recharge promptly.

4.Charging:Connect the charger to the Type-C port. The battery icon will stay lit, and the percentage will flash to indicate real-time charging status. Display shows "100%"when fully charged.

5.Please Note: Do not activate ice pack mode while charging.

Product Accessories



Warnings

◆This product has a built-in sealed battery. Do not disassemble it by yourself.

◆Do not use in humid environments (e.g., bathrooms). Exposure to water may cause malfunction or damage.

◆Avoid impacts or dropping the product. Repeated shocks may damage internal components.

◆Do not disassemble, modify, or repair the product yourself.

◆Do not expose to fire or high heat to prevent explosion risks.

◆If abnormal overheating or deformation occurs during charging, stop use immediately and contact customer service.

◆Do not allow children under 7 years old to use this product unsupervised.

Product Certification

|                    |                         |
|--------------------|-------------------------|
| Product Name:      | High Speed Handheld Fan |
| Product ID:        |                         |
| Model:             | HL005                   |
| Production Date:   |                         |
| Quality Inspector: | 01                      |

技术要求

1.印刷必须清晰不得有断线、模糊不清等不良现象；

2.背胶必须耐温80摄氏度且不会翘起；

3.标签必须符合“SPI环境管制物质技术标准（SGP-0401）”最新版。

4.公差为±0.1mm。

温馨提示：请印刷供应商严格按照我司设计图纸印刷生产。如贵司有生产上的原因需要调整图纸的字体、图形、颜色、刀模尺寸、材质工艺等，请必须通知我司相关负责的包装设计师，并在征得包装设计师同意的情况下修改文档并发回存档。

大花猫科技

Greatarmo Technology Co.,Ltd

型号

HL005

物料

说明书

颜色

黑白

材质

80g书纸

工艺

单色

设计

日期

2026年03月05日

尺寸

70×105mm

公差±0.1

审核

日期

单位

mm

页码

1

批准

日期

比例

1:1

版本

V1.0