修改标记	区域	修改内容	修改人	日期

便携式挂腰风扇

W7使用说明书

安全指引

1.本产品不得由存在肢体、感官或精神能力缺陷或缺少使用经验和知识的人(包括儿童)使用,除非有负责他们安全的人对他们进行与本产品使用有关的监督或指导。
2.在使用本产品时应照看好儿童,确保他们不玩耍本产品。
3.本产品应仅使用标记在机身上的安全特低电压供电。
4.本产品包含只能由技术人员更换的电池。
5.本产品说明书电子档，官方下载网站：https://www.greatarmo.com

产品参数

产品名称	便携式挂腰风扇
产品型号	W7
充电输入	5V⎓1.8A
电池电压	3.7V
产品尺寸	85.5*75.6*89mm
执行标准	GB/T 4706.1-2024 ,GB/T 4706.27-2024

使用前请仔细阅读说明书，并保管好说明书

产品结构



使用说明

% 电量百分比　　风扇图标

1:向左拨动电源键开机，同时显示屏显示当前电量。
2:单击风量按键，开启风扇，显示屏显示当前风扇档位，风速默认为01档，继续单击按键，增加风速，默认循环档位顺序依次为：01-25-50-75-100-关机。
3.停止按键操作后，当前档位显示保持3S;然后切换到显示当前电量，20S后熄屏。
4:电量低于10%时.显示屏闪烁提醒.请及时进行充电。
5:充电：插入充电线后，电量百分比个位数闪烁，显示实时电量，电池充满后显示屏显示100%。

产品配件

彩盒一套　说明书一张　数据线一条　挂绳一条　产品一台

警告

◆ 本产品内置密封电池，无法自行拆卸。
◆ 请勿在潮湿环境中（如浴室）使用本产品，接触水可能会导致产品故障或损坏。
◆ 请勿敲击或摔打本产品，反复敲击可能会导致内部损坏
◆ 请勿自行拆卸、更改或者修理本产品。
◆ 请勿将产品投入火中，以免发生爆炸危险。
◆ 若产品在充电过程中出现异常高温或变形，请立即停止充电并联系售后服务中心处理。
◆ 请勿让7岁以下儿童单独使用本产品。

产品合格证

产品名称：	便携式腰部风扇
产品编号：	
产品型号：	W7
生产日期：	
检验员：	01

PORTABLE WAIST FAN

W7 User manual

Safety Instructions

1.This product must not be used by persons with physical, sensory or mental impairments, or by those lacking experience and knowledge (including children), unless they are supervised or instructed by a person responsible for their safety in relation to the use of this product.
2.Children shall be supervised when this product is in use to ensure they do not play with it.
3.This product shall be powered only by the safety extra-low voltage (SELV) marked on the unit.
4.This product contains batteries that can only be replaced by a qualified technician.
5.Electronic version of this product manual is available for official download at: https://www.greatarmo.com

Product Specifications

Product Name	PORTABLE WAIST FAN
Model	W7
Charging Input	5V⎓1.8A
Battery Voltage	3.7V
Product Size	85.5*75.6*89mm
Compliance Standard	GB/T 4706.1-2024 ,GB/T 4706.27-2024

Please read the manual carefully and keep it well before use

Product Structure



Instructions for Use

% Battery Percentage

1.Slide the power key left to power on. The current battery level will be displayed on the screen simultaneously.
2.Short press the wind speed button to activate the fan. The current fan level will appear on the screen, with the default speed set to Level 01. Press the button repeatedly to adjust the wind speed. The cycle sequence is: 01 - 25 - 50 - 75 - 100 - Power Off.
3.After all button operations stop, the current level will stay on screen for 3 seconds, then switch to display the current battery level. The screen will turn off after 20 seconds.
4.When the battery level drops below 10%, the screen will flash as a reminder. Please charge the device promptly.
5.Charging: After connecting the charging cable, the units digit of the battery percentage will flash and the real-time battery level will be shown. The screen will display 100% once fully charged.

Product Accessories

Gift Box x1　User Manual x1　USB Cable x1　Lanyard x1　Product x1

Warnings

◆ This product has a built-in sealed battery. Do not disassemble it by yourself.
◆ Do not use in humid environments (e.g., bathrooms). Exposure to water may cause malfunction or damage.
◆ Avoid impacts or dropping the product. Repeated shocks may damage internal components.
◆ Do not disassemble, modify, or repair the product yourself.
◆ Do not expose to fire or high heat to prevent explosion risks.
◆ If abnormal overheating or deformation occurs during charging, stop use immediately and contact customer service.
◆ Do not allow children under 7 years old to use this product unsupervised.

Product Certification

Product Name:	Portable Waist Fan
Product ID:	
Model:	W7
Production Date:	
Quality Inspector:	01

技术要求

1.印刷必须清晰不得有断线、模糊不清等不良现象；
2.背胶必须耐温80摄氏度且不会翘起；
3.标签必须符合“SPI环境管制物质技术标准（SGP-0401)”最新版。
4.公差为±0.1mm。

温馨提示：请印刷供应商严格按照我司设计图纸印刷生产。
如贵司有生产上的原因需要调整图纸的字体、图形、颜色、刀模尺寸、材质工艺等，请必须通知我司相关负责的包装设计师，并在征得包装设计师同意的情况下修改文档并发回存档。

大花猫科技
Greatarmo Technology Co.,Ltd

型号	W7	物料	说明书			颜色	黑白
材质	80g书纸		工艺	单色			
设计		日期	2026年03月05日	尺寸	85×75mm		公差±0.1
审核		日期		单位	mm	页码	1
批准		日期		比例	1:1	版本	V1.0